

SIMPLIFIED APHROMETER



Instruction manuel

This aphrometer is composed of three main parts:

- A stainless steel pressure vacuum gauge – 1 + 1,5 bar.
- A copper gasket.
- A simplified needle.

Before to use:

- Ensure that the cork is visible.

Before to use:

- Put the needle on top of the cork.
- Ensure that the needle is centre.
- Gently push the needle inside the cork. Keep the aphrometer vertical while pushing.

To disengage the aphrometer:

- Gently pull the aphrometer.
- Ensure that the needle holes are not clogged.

For a better understanding of our aphrometer see the other side of the sheet.



May differ from photograph

LIGAPAL - 17 rue du commerce - 51350 Cormontreuil - France

tél. / phone : (+ 33) 326 05 05 28

information : info@ligapal.com - **international :** export@ligapal.com

www.ligapal.com